




Pos.	Description	Part.no	PC
1	fixed seat	Q2W0040BCP	1
2	screw	L5W0003BSC	1
3	fixed seat	M2W0011TQH	1
4	protective case	Q2W0030BCP	1
5	pipe	M2W0011TQH	1
6	O-ring	R1W0101RSC	3
7	head shower	L-5401	1
8	support, assy	M2W0020TQH	1
9	hand shower	L-5402	1
10	shower hose	L-5285	1
11	pipe	M2W0011TQH	1
12	O-ring	004038R	1
13	connector	039082B	1
14	glass cover	002027G	1
15	cover	002017P	1
16	button	029078P	3
17	cover	104015B	3
18	cartridge	024033WZ	3
19	hydraulic generator	001021P	1
20	glass	002021G	1
21	hand wheel handle	029077B	1
22	cover	104015B	1
23	gasket	207037P	1
24	cover	104015B	1
25	water diverter valve core	024038WZ	1
26	check valve	988004P	2
27	open washer	207038P	2
28	set of S-unions	039084B	2
29	screw	053009S	2
30	main body	044029B	1
31	decorative cup	103011P	2
32	double layer rubber pad	088001R	2
33	screw	008001S	1
34	screw cover	028002R	1
35	screw	053009S	2
36	O-ring	004038R	1
37	screw	008010S	2

Pos.	Description	Part.no	PC
38	connector	039082B	1
39	aerator housing	305003B	1
40	aerator	500001P	1
41	double layer rubber pad	088001R	1
42	cover	033074P	1